

Mounting instruction  
Triumph Classic Dynamic belt tensioner  
(code 307551)



Installation time : 5 minute

Tools Requirement : 1) 5-6mm. Allen wrench  
2) Drill  
3) Countersink bit  
4) Medium thread locker



1

Countersink the hole as photos.



2

Insert countersunk head bolt M10x40.  
Insert button head bolt m10x45.



3

Insert spacers as photos.

